

INFINITY PHOTO-OPTICAL 45° and 90° PRISM ASSEMBLY GUIDE

Setup for 45° Prism and 90° Prism (Shown)

REFER TO ROADMAP INSTRUCTIONS FOR ADDITIONAL INFO

Micro HM



UNSCREW SPACER



SCREW ON PRISM



* Install 8mm Spacer

ASSEMBLED



SFX-1



* Install 5mm Spacer



SFX-2



* Install 5mm Spacer



SFX-3



* Install 8mm Spacer



Macro Pro



No Prisms Used

* Each Prism comes with 5mm and 8mm spacer

45° Prism



Assembled

90° Prism



Assembled

FlipR



Unlock Horizon Adjust To Level Image

